



Inside Frame - Recess

Check if depth of the Frame Recess is enough to accommodate the screen frame and tracks. Screen diagram dimensions on the second page of this guide.

Check for any obstructions like handles or locks and if any ensure to check the distance from the handle/lock to the edge of the frame.

Measure the **Width** in at least two points and use the smallest dimension.

Measure the **Drop** in at least two points and use the smallest dimension.



Outside Frame - Exact

On an outside measurement take into account frame and tracks dimensions. Frame and Tracks should be placed on an even surface and without overlapping the frame recess for optimal finish.

Installing on the frame trim is ideal as long as the trim can accommodate the screen frame.

If a trim exists but not wide enough installation may still be possible using packers for stability.

Wall installation follows the same steps and packers may be used if required.

Measure the **Width and Drop**

*These instructions are for the most common possible ways to measure and if unsure contact us for advice.

- No Deductions are applied during manufacturing, sizes provided will be the finished size for your screen.



scan to chat

